

2009+ FORD F-150 REPLACEMENT PILLAR INSTALLATION INSTRUCTIONS





1. Remove dash side panel. (applicable for speaker models only)



2. Disconnect factory speaker. (applicable for speaker models only)



3. Remove factory pillar.



4. Install factory speaker into the new pillar. (applicable for speaker models only)



Thread screw onto well nut.



6. Place well nut into slot, then remove the screw.



7. Align tabs on bottom of pillar with factory slots in dashboard.



 Insert screw through pillar into well nut and tighten. (See note below.)



Pillar sits behind door weather stripping.



10. Be sure pillar fits behind factory dashboard trim.

NOTE: Normally you would have already pre-wired your gauges and had them partially inserted into the pillar for final assembly.

Auto Meter Gauge Works Three Year Limited Warranty

Gauge Works warrants to the consumer that all Auto Meter Gauge Works products will be free from defects in material and workmanship. Products that fail will be repaired or replaced at Auto Meter Gauge Works' option to the consumer, when determined by Auto Meter Gauge Works that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the Auto Meter Gauge Works Product and the necessary labor done by Auto Meter Gauge Works to effect the repair or replacement of the Auto Meter Gauge Works product. In no event shall this warranty exceed the original purchase price of the Auto Meter Gauge Works product nor shall Auto Meter Gauge Works be responsible for special, incidental or consequential damages or costs incurred due to the failure of this product. Warranty claims to Auto Meter Gauge Works must be transportation prepaid and accompanied with proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. Improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. Auto Meter Gauge Works disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by Auto Meter Gauge Works. This warranty is made solely by Gauge Works with Auto Meter being the agent to contact for warranty claims. If the partnership between Auto Meter and Gauge Works dissolves, then all warranty adjustments will be covered by the Gauge Works Co.